



Airbed with Silent Night[™] Comfort Adjust Back-Up Pump[™]

This product may be covered under one or more of the following U.S. and / or foreign patents: U.S. Pat. Nos.: 2,425,162; 5,827,052; 6,004,116; 6,332,670 B1; 6,457,192; 6,581,223; 6,679,686 B2; 6,722,306 B1; 6,754,925 B1; 6,754,926 B2; 6,763,540; 6,793,469; 6,990,700 B2; 7,020,921 B2; 7,040,347 B2; 7,114,207; 7,120,955; 7,152,265; 7,246,394; 7,306,694; 7,313,837; 7,334,274; 7,346,950 B2; 7,365,277; 7,475,443; 7,597,123; 7,647,662; 7,739,760; 7,703,160; 7,739,763; GB2378987; GB2396670; CN 221,800; ZL01129383 Others U.S. and International Patents Pending



For better protection of this product, never unfold or inflate the airbed in temperatures below freezing, avoid extensive exposure to the sun and protect from contact with sharp objects and rough ground. Make sure to handle the pump with care. Avoid pounding and jumping to prevent damage to the airbed material.

Setup Operations: (Before inflating, Plug into AC Power outlet.)




Turn the Silent Night Pump Dial to desired firmness level.




Turn Inflate/Deflate Switch clockwise to "Inflate" position to turn on Setup Pump and inflate air bed.
Setup Pump will automatically turn off upon reaching selected firmness.

off upon reaching selected firmness level and Inflate/Deflate Switch will automatically return to "Off" position.


Silent Night Comfort Adjust Back-Up Pump Operations:



The Silent Night Comfort Adjust Pump is a fully automatic pressure maintenance pump that is designed to operate silently so that it will not disturb your sleep when it automatically turns on to re-inflate. Pump will automatically turn on when air pressure inside air bed drops below a predetermined low pressure level. Pump will automatically turn off upon reaching selected firmness level (firmness determined through adjusting the Pump Dial).




To ensure that the Silent Night Pump will operate, please make sure to plug power cord into 120V AC electrical wall socket.




To turn off the Silent Night Pump auto inflate function; turn Pump Dial to "Off" position. The Silent Night Pump will not automatically turn on regardless of air pressure inside airbed.

Takedown Operations:



Turn the Silent Night Pump Dial to "Off" position so the Pump will not automatically turn on.



Turn Inflate/Deflate Switch counterclockwise to "Deflate" position for complete air removal.

Upon complete air removal, Setup Pump will automatically turn off and Inflate/Deflate Switch will automatically return to "Off" position. Place power cord into Cord Storage Pocket for storage.

IMPORTANT SAFETY INSTRUCTIONS:

When using an electrical furnishing, basic precautions should always be followed, including the following: READ ALL INSTRUCTIONS BEFORE USING.

DANGER- To reduce the risk of electric shock. Always unplug this appliance from the electrical outlet before cleaning.

WARNING- To reduce the risk of bums, fire, electric shock, or injury to persons:

- 1. Unplug from outlet before putting on or taking off parts.
- 2. Close supervision is necessary when this appliance is used by, or near children, invalids or disabled persons.
- 3. Use this appliance only for its intended use as described in this manual. Do not use attachments unless recommended by the manufacturer.
- 4. Never operate this appliance if it has a damaged cord or plug, if it is not working property, if it has been dropped or damaged or dropped into water, return to a service center for examination and repair.
- 5. Keep the cord away from heated surfaces.
- 6. Never operate the appliance with the air openings blocked. Keep the air openings free of lint, hair and the like.
- 7. Never drop or insert any object into any opening.
- 8. Do not use outdoors. For Household Use Only.
- 9. Do not operate where aerosol (spray) products are being used or where oxygen is being administered. Keep the pump away from flammable liquid. The area where the pump is used should be well ventilated.
- 10. To disconnect turn all controls to the off position then remove plug from outlet.
- 11. To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way, if the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician to install the proper outlet. Do not change the plug in any way.
- 12. Power supply for pump must be 120V AC.
- 13. It is not recommended to plug into the 120V power source unattended when not in use.
- 14. Do not obstruct ventilation hole on pump.
- 15. Do not open the pump case-electrical hazard may result. No user serviceable parts.
- 16. Do not over-inflate.
- 17. For proper Setup Pump usage, it is recommended not to exceed 5 minutes of continuous inflation/deflation time.
- 18. In case the pump overheats due to excessive continuous inflation/deflation, the power will automatically cut off and reset to begin working within 30 minutes.
- 19. The Setup Pump included in this airbed is thermally protected.
- 20. A fire may occur if this devices touches or is covered by flammable material, including curtains, draperies, walls, etc., when in operation.
- 21. DO NOT place any flammable material such as paper, cardboard, plastic on the pump.
- 22. DO NOT operate the pump in enclosed spaces that are not well-ventilated.
- 23. DO NOT operate in the presence of explosive and/or flammable fumes.
- 24. DO NOT place any part of the pump or cord in or under water or other liquid.
- 25. DO NOT leave device unattended when in operation.
- 26. DO NOT over inflate.
- 27. Do clean airbed with only damp cloth soaked in mild soap and water.
- 28. **WARNING:** The Maximum Weight Capacity for the Queen Size is 500lbs, Full size is 400 lbs and Twin size is 250 lbs.
- 29. Do not use near people using or wearing medical devices.

SAVE THESE INSTRUCTIONS

SERVICING OF DOUBLE-INSULATED PRODUCTS

This appliance is double insulated. In a double-insulated product, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated product, nor is a means for grounding to be added to the product. Servicing a double-insulated product requires extreme care and knowledge of the system, and is to be done only by factory qualified service personnel. Replacement parts for a double-insulated product must be identical to the parts they replace.

NOTE:

Airbed material may stretch during first use and may need additional air to reach desired firmness. Air inside of bed may expand and contract with varying temperatures potentially leading to reduced pressure inside of the bed. If this occurs, simply add more air using the built-in pump to achieve desired firmness.

For better protection of this product, never unfold or inflate the airbed in temperatures below freezing, avoid extensive exposure to the sun and protect from contact with sharp objects and rough ground. Make sure to handle the pump with care.

CARE AND MAINTENANCE:

Clean airbed with only damp cloth soaked in mild soap and water.

REPAIRING (Repair kit included):

First, deflate the bed by following the instructions for deflation. Clean and repair the affected area thoroughly. Cut a piece of clear patch material (included in the repair kit) into a size that will cover the puncture. Apply the self-adhesive patch over the affected area by peeling off the backing and placing sticky side down on airbed. Rub patch to ensure adhesion. Allow four (4) hours for repair to set before attempting to inflate the airbed. Any other servicing is to be performed by an authorized service representative.

IMPORTANT SAFETY INFORMATION AND WARNINGS

Adult supervision required for setup. Warning this is an electrical product. To avoid risk of fire, burns, injury, and shock, it should not be played on or placed near where small children can reach it. Do not use in or around water. Not to be used outside, this bed is for indoor use only. The bed should be placed in an open area before use. Making sure there are no sharp objects, steps, drops, or breakable objects in the area. Unplug when not being used.